DAREU

# User Manual

Keycap puller x1

Cable x1

Switch puller x1

EK861
Hotswap Keyboard

User manual x1

Keyboard x1

2.4GHz dongle x1

*In red when charging. And turns green when complete.

Suitable for all PC devices by cable.

Parameter

Keyboard type: 60% (61 keys)

Connection way: wired + BT + 2.4GHz

Operating distance: <10 m (Wireless mode)

Keycap: ABS with double injection   Switch: Hot-swap switch

Weight: 591±10g (Not include cable)   Dimension: 290 x 100 x 42 mm

Key conflict: N-Key rollover   Backlight: RGB

Battery: 1900 mAh   Working voltage: 5V

Working current: 160mA

Compatibility: Win 7 and later / Mac OS / Android

How to Connect

A 📶 BT₁ BT₂

Channel A : Wired

Channel 📶 : 2.4GHz

Channel BT₁ BT₂ : BT

Support multiple platforms

A： Connect with the cable and use. (If in wireless mode, it turn off.)

📶： Plug and play. Switch button to this position, insert the dongle and use.

If it fails, press Fn+Q for 5 seconds, the indicator light(Esc) flashes quickly.

Insert the dongle, and pair it for use.

BT： 1- Switch button to this position.

2- Turn on the device BT and search keyboard.

3- Pair and connect.

*If can't search the keyboard or want to connect to another devices, press Fn+Q for 5 seconds, the indicator light(Esc) flashes quickly. Then pair it for use.

Adjustable magnetic keyboard feet

90 degrees rotating

It will make keyboard higher for 3.5mm
by taking keyboard feet out and rotating it by 90 degrees

Li-Battery built inside with long battery life

Backlight switch

Fn + **L** = Switch the backlight (Total 20 lighting modes)

Fn + **>** = Switch the backlight color

Fn + **Tab** = Reset the backlight (Long press for 5 seconds)

Fn + [brightness slider] = Backlit brightness control (Cycle: 100%-OFF-25%-50%-75%)

*In wireless mode, if there is no key operation for 5 minutes, the backlight is automatically turned off, and wake up on any key.

**Fn** + [Alt] [≣] [Ctrl] [/?] ⇨ [▲] [◄] [▼] [►]

Fn + **O** = [Alt] [≣] [Ctrl] [/?] ⇔ [▲] [◄] [▼] [►] — Combo keys in 5s, then arrow keys exchanged.

After arrows key exchanged

Fn + [?/ ▲] = [/]

[↑ Shift (Right)] + [?/ ▲] = [?]

Key shortcuts

Fn +

1.F1~F12

2.Volume control

3. Screen brightness control

4.Function Key

Key Function

Fn + Esc = ` `

Fn + ↑ Shift + Esc = ~

Fn+" Y "= Prscr   Fn+" U "= ScrLk   Fn+" I "= Pause   Fn+" H "= Ins

Fn+" J "= Home   Fn+" K "= PgUp   Fn+" M "= End   Fn+" , "= PgDn

Fn+" ←"= Delete   Fn+" Win "= WIN Lock/Unlock

Fn+" W "=L-Win ⚡ L-Alt (Long press for 5s)

How to use driver

Download the driver from DAREU website if needed.

*Pictures are for reference only, please log in: www.dareu.com to learn more.

1

Driver interface

2

Marco interface

EK861

Hotswap Keyboard