


DAREU  **A⁺**

User Manual





Mouse x1




cable x1



Charging dock x1




User manual x1



- ① Left button
- ② Right button
- ③ Scroll wheel
- ④ DPI button
- ⑤ Forward button
- ⑥ Backward button

Magnetic charging contacts

Connection modes switch



BT pairing
(Press 5 seconds)

Receiver case


Connection: wired / 2.4G / BT	Cable length: 1.5 meters
Acceleration: 35G	Tracking speed: 300 IPS
DPI(BT): 800/1200/1600(default)	Battery: 930mAh
DPI(wired/2.4G): 400/800/1600(default)/3200/6400 (Max 12000)	
Report rate: 1000Hz(wired/2.4G); 125Hz(BT)	
Working time(wireless): approx. 12 days (2.4G); approx. 30 days (BT)	
Charging time: approx. 2.5 hours by wire; approx. 4 hours by charging dock.	
Weight: 88±5g (Not including cable and charging dock)	
Dimension: 123*64*39mm	
Compatibility: Windows/MaC OS/Android/IOS and so on	

Logo indicator light


When battery power is lower than 20%, the decorative light flashes red;

When charging, the decorative light turns green;

When battery power exceeds 90%, the decorative light will change back to original lighting effects.



2.4G: switch bottom button to 2.4G mode, insert the dongle and use.



Wired: wherever the mode button stays (either on 2.4G or BT mode), mouse will be in wired mode once cable is plugged in.



BT: 1- Switch button to BT mode;

2- Turn on BT of the device, and search "A950 BT";


3- Pairing then use.

*In BT mode, if can't search the mouse, press bottom BT pairing button (5 seconds), then pair it and use.

Driver interface


Download driver from Dareu's official website (www.dareu.com) and install it on computer. (Driver only supports Windows systems.)

*Picture is for reference only.



How to set macro function

- ① Create a new macro;
- ② Before recording, we can check the options we need;
- ③ Click **Start Recording**, then set the macro definition;
- ④ When finished, click **Stop Recording**;
- ⑤ Save and back to **Key Setting** page;
- ⑥ Press the key which we want to set the macro; (If want to set the macro definition for the Left/Right button, we must set other button to the Left/Right button first, otherwise the mouse will not work normally.)
- ⑦ Select the Macro option;
- ⑧ Select the Macro Definition which we recorded and confirm **OK**.



A950

Dongguan Togran Electronics Technology Co., Ltd
Add: No. 110, Shijie Shidan Mid Rd, Shijie Town, Dongguan City,
Guangdong Province, China 523290

Tel: +86 769 86308806 Fax: +86 769 86308826
Email: Info@dareu.com CS@dareu.com
Web: www.dareu.com